

## AIRPORT LOCAL GUIDELINES

# ANTALYA AIRPORT

ICAO CODE	LTAI	
IATA CODE	AYT	
IATA LEVEL	Level 2 in Winter seasons (SMA) , Level 3 in Summer seasons(SCR)	
Phone	0 242 330 30 30	Ext: 1153 / 1593
E-mail	<a href="mailto:ltai.ramp@dhmi.gov.tr">ltai.ramp@dhmi.gov.tr</a>	

### PARKING COORDINATION PARAMETERS

GA/BA flights	Ground time is more than <b>24</b> hours => coordinate with Ramp					
Wingspan Category C &D (A320,B737, A310, B767 etc.)	Ground time is more than <b>8</b> hours => coordinate with Ramp					
Wingspan Category E (A333, A346, B742, B777 etc.)	Ground time is more than <b>8</b> hours => coordinate with Ramp					
Wingspan Category F (A4F, A388, B747, C5 etc.)	For all requests => coordinate with Ramp					
Paxflow capacity per hour (T60)	<b>DOM</b>			<b>INT</b>		
	<b>ARR</b>	<b>DEP</b>	<b>TOTAL</b>	<b>ARR</b>	<b>DEP</b>	<b>TOTAL</b>
	8834	2360		10567	4650	
Parking Constraints	Limited Parking area					
Prohibited service types	"X" for summer seasons					
Prohibited aircraft types	A4F, A388, B747, C5					
Special Condition	Aircraft types AN124, AN225, C5, A380, B747-800 are not allowed to land at the aerodrome. (Except presidential aircraft and special permitted aircraft) March 01 – December 01 training flights are not allowed due to high traffic intensity at Antalya Aerodrome.					
Runway capacity per hour (R60)	<b>ARR</b>		<b>DEP</b>		<b>TOTAL</b>	
0	35		35		65	
1	35		35		65	
2	35		35		65	
3	35		35		65	
4	35		35		65	
5	35		35		65	
6	35		35		65	
7	35		35		65	
8	35		35		65	
9	35		35		65	
10	35		35		65	
11	35		35		65	
12	35		35		65	
13	35		35		65	
14	35		35		65	
15	35		35		65	
16	35		35		65	
17	35		35		65	
18	35		35		65	
19	35		35		65	
20	35		35		65	
21	35		35		65	
22	35		35		65	
23	35		35		65	