

LTBW AD 2.1 AERODROME LOCATION INDICATOR AND NAME**LTBW - İSTANBUL - HEZARFEN****LTBW AD 2.2 AERODROME GEOGRAPHICAL AND ADMINISTRATIVE DATA**

1	ARP coordinates and site at AD	410615N-0283300E, At Apron
2	Direction and distance from (city)	37 KM NW of İstanbul Atatürk (LTBA) AD and 38 KM SW of İstanbul (LTFM) AD.
3	Elevation/Reference temperature/Mean low temperature	61 FT / 25° C / -2° C
4	Geoid Undulation at AD ELEV PSN	122 FT
5	MAG VAR/Annual change	6.0°E (2023) / 0.1° increasing
6	AD Administration, address, telephone, telefax, telex, AFS	Hezarfen Havalimanı Bahşayış Mah. Aksaray Cad. No:7 34180 Çatalca İstanbul / TÜRKİYE Switchboard : +90 212 6396300 Fax : +90 212 8871462 Tower Tel : +90 212 8871460 Tower Fax : +90 212 8871452 E-mail : hezarfen@hezarfen.com.tr AFS : LTBWHEZR
7	Types of traffic permitted (IFR/VFR)	VFR Local flight may be limited by ATC.
8	Remarks	Only available for MTOW 5700 KG Aircraft

LTBW AD 2.3 OPERATIONAL HOURS

1	AD Administration	See NOTAM
2	Customs and immigration	Not available
3	Health and sanitation	Not available
4	AIS Briefing Office	Not available
5	ATS Reporting Office (ARO)	Not available
6	MET Briefing Office	Not available
7	ATS	As AD Working Hours
8	Fueling	Not available
9	Handling	Not available
10	Security	H24
11	De-icing	Not available
12	Remarks	NIL

LTBW AD 2.4 HANDLING SERVICES AND FACILITIES

1	Cargo-handling facilities	Not available
2	Fuel/oil types	Not available
3	Fuelling facilities/capacity	Not available
4	De-icing facilities	Not available
5	Hangar space for visiting aircraft	Not available
6	Repair facilities for visiting aircraft	Not available
7	Remarks	NIL

LTBW AD 2.5 PASSENGER FACILITIES

1	Hotels	In the city.
2	Restaurants	Restaurant at AD.
3	Transportation	Not available
4	Medical facilities	Hospital in the city.
5	Bank and Post Office	In the city
6	Tourist Office	Not available
7	Remarks	NIL

LTBW AD 2.6 RESCUE AND FIRE FIGHTING SERVICES

1	AD category for fire fighting	Category 1
2	Rescue equipment	Fire truck with 6 ton water capacity and 400 liter/minute foaming capability. Zodiac search and rescue boat. 60 fire-extinguishers with dry chemical powders.
3	Capability for removal of disabled aircraft	Disabled aircraft removal facilitation is carried out by Hezarfen Airport Directorate. This action is charged according to the Hezarfen Airport Charge Tariff Table.
4	Remarks	NIL

LTBW AD 2.7 SEASONAL AVAILABILITY - CLEARING

1	Types of clearing equipment	1 RWY sweeper, 1 RWY snow removal.
2	Clearance priorities	RWY, TWY, Apron
3	Remarks	NIL

LTBW AD 2.8 APRONS, TAXIWAYS AND CHECK LOCATIONS POSITIONS DATA

1	Apron surface and strength	North and South Apron: Concrete (Allowable aircraft mass: Less than 5700 Kg)
2	Taxiway width, surface and strength	Width: TWY A, D: 25 M. C, B: 12 M. E: 7,5M. F: 9 M. G: 4 M - Asphalt
3	Altimeter Check Point location and elevation	North Apron: 18 M. South Apron: 14 M

4	VOR checkpoints	Not available
5	INS checkpoints	See AD Parking Chart
6	Remarks	NIL

LTBW AD 2.9 SURFACE MOVEMENT GUIDANCE CONTROL SYSTEM AND MARKINGS - NIL

LTBW AD 2.10 AERODROME OBSTACLES - NIL

LTBW AD 2.11 METEOROLOGICAL INFORMATION PROVIDED

Meteorological information obtained from LTBA, LTFM and LTBU Airports and also available at 128.2 MHz VOLMET.

LTBW AD 2.12 RUNWAY PHYSICAL CHARACTERISTICS

Designations RWY NR	TRUE BRG	Dimensions of RWY (M)	Strength (PCN) and surface of RWY and SWY	THR coordinates RWY End Coordinates THR Geoid Undulation	THR elevation and highest elevation of TDZ of precision APP RWY
1	2	3	4	5	6
05	055.69°	535X18	Asphalt (Allowable aircraft mass: Less than 5700 Kg.)	410607.39N- 0283241.38E - GUND: 122 FT	THR 7.9 M / 26 FT
23	235.69°	535X18	Asphalt (Allowable aircraft mass: Less than 5700 Kg.)	410617.39N- 0283300.08E - GUND: 122 FT	THR 18.5 M / 61 FT

Slope of RWY-SWY	SWY dimensions (M)	CWY dimensions (M)	Strip dimensions (M)	RESA (M)	Arresting System	OFZ	Remarks
7	8	9	10	11	12	13	14
1.98%	-	-	595X60	30X36	-	-	NIL
1.98%	-	-	595X60	30X36	-	-	

LTBW AD 2.13 DECLARED DISTANCES

RWY Designator	TORA (M)	TODA (M)	ASDA (M)	LDA (M)	Remarks
1	2	3	4	5	6
05	535	535	535	535	NIL
23	535	535	535	535	

LTBW AD 2.14 APPROACH AND RUNWAY LIGHTING - NIL

LTBW AD 2.15 OTHER LIGHTING, SECONDARY POWER SUPPLY

1	ABN/IBN location, characteristics and hours of operation	-
2	LDI location and LGT Anemometer location and LGT	-
3	TWY edge and centerline lighting	-
4	Secondary power supply/switch-over time	-
5	Remarks	OBST, ABN Standard Visual Marking Aids available.

LTBW AD 2.16 HELICOPTER LANDING AREA

Helicopter landing area is not available. Helicopters conducting landing and take-off operations shall abide by the ATC instructions.

LTBW AD 2.17 ATS AIRSPACE

1	Designation and lateral limits	CTR: Centered on 410615N-0283300E Radius 3 NM
2	Vertical limits	1500 FT AMSL/SFC
3	Airspace classification	NIL
4	ATS unit call sign Language(s)	Hezarfen Control Tower TU-EN
5	Transition altitude	12000 FT
6	Remarks	NIL

LTBW AD 2.18 ATS COMMUNICATION FACILITIES

Service designation	Call sign	Channel	Hours of operation	Remarks
1	2	3	4	5
TOWER	Hezarfen Tower	118.25 MHz 121.65 MHz *121.5 MHz	SR/SS	*Emergency
	Hezarfen Ground	121.65 MHz	SR/SS	-

LTBW AD 2.19 RADIO NAVIGATION AND LANDING AIDS - NIL

LTBW AD 2.20 LOCAL TRAFFIC REGULATIONS

MEYDAN KULLANMA TEDBİRLERİ

a) **Eğitim Uçuşları:** Hezarfen CTR ve eğitim alanları (ENR 5.5) dahilinde gerçekleştirilecek eğitim uçuşlarına ilişkin Uçuş Bilgileri, sadece arşiv amaçlı olarak toplanacak ve gerekmedikçe İstanbul Havalimanı ATS birimlerine FPL amacıyla gönderilmeyecektir.

LIMITATIONS ON USE OF AERODROME

a) **Training Flights:** Flight Information pertaining to training flights to be performed within the Hezarfen CTR and training areas (ENR 5.5) will only be collected for keeping purposes and will not be sent to ATS units of İstanbul Airport for FPL purposes unless so required.

b) Hezarfen Havaalanına dış meydanlardan planlanan tüm inişler Hezarfen Havaalanı Müdürlüğünün onay ve iznine tabidir.
Uçuş planlanmadan önce Hezarfen Havaalanı Müdürlüğünden izin alınması gerekmektedir.

b) All planned landings at Hezarfen Airport from other airports are subject to the approval and permission of the Hezarfen Airport Directorate.
Before planning the flight, permission must be obtained from the Hezarfen Airport Directorate.

LTBW AD 2.21 NOISE ABATEMENT PROCEDURES - NIL

LTBW AD 2.22 FLIGHT PROCEDURES - NIL

LTBW AD 2.23 ADDITIONAL INFORMATION

Hezarfen Havaalanı ana göç yolları üzerindedir.
- İlkbahar göç dönemi; Mart-Nisan-Mayıs ayları boyunca göçmen kuş hareketliliği (15 Mart-10 Nisan ilkbaharın en yoğun zamanı) görülmektedir.
- Sonbahar göç dönemi; Ağustos, Eylül, Ekim, Kasım ayları boyunca göçmen kuş hareketliliği (25 Eylül-05 Ekim ve 15 Ekim-05 Kasım sonbaharın en yoğun zamanı) görülmektedir.

Hezarfen Airport is on the main bird migration routes.
- Spring migration period; during March-April-May the migratory bird movements (peak period between 15 Mar-10 Apr).
- Autumn migration period; migratory birds movement during the months of August, September, October and November (25 Sep-05 Oct and 15 Oct-05 Nov is the peak time of autumn).

LTBW AD 2.24 AERODROME CHARTS

Aerodrome Chart	AD 2 LTBW ADC
Aircraft Parking/Docking Chart	AD 2 LTBW PRKG